


# **ELECTRIC TRICYCLE**

**PLEASE READ THE MANUAL  
CAREFULLY BEFORE USE**



# MAIN SPECIFICATION

---















Name	Electric Tricycle
Power Source	6V-4.5AH Airtight dry type accumulator cell
Motor	6V-15W
Suitable Age	37-95months
Maximum Capacity	30KG
Vehicle Size	81*43*55CM
Maximum Speed	3km/h
Charging Time	8-12h
Battery Charger	Input AC220V、50HZ, Output DC6V、500MA
Fuse	15A

# WARNING

---


- 1) This product is non-transportation vehicle, it only be used on the safety flat ground under adult supervisor.
- 2) The vehicle should be assembled by adult before use.
- 3) All the electric cycles' battery charger are not children's toys, they must be operated by adult, users should notice any charger is dangerous to children. Before use this product, please charge first.
- 4) Before use this vehicle, must read the instruction carefully and it should be well reserved for the future use.
- 5) After opening the box, plastic bags are dangerous to children, should be handled properly.
- 6) This product is forbidden for water washout, spray and wash.
- 7) Must cut off the power switch when you don't use the product, if longtime no use this product, please make sure the battery is charged up full to extend the life span of battery.
- 8) The vehicle is only for one person, the weight should be under 30KG.

COMPONENT

NO	NAME	PICTURE	QTY	NOTE	NO	NAME	PICTURE	QTY	NOTE
1	body		1		2	dash board		1	
3	handle		1		4	front axle		1	
5	head		1		6	seat		1	
7	winds hield		1		8	front wheel		1	
9	reflec tor		1		10	tool box		1	
11	3*8mm self-taping screw		6		12	4*16mm self-taping screw		4	
13	driving motor		1		14	charger		1	

# ASSEMBLY

---




## 1) Assemble the front wheel

- 1.Embed the mudguard according to the picture.
- 2.Take out the nut and gasket,insert the front axle go though the fork and wheel,then put one gasket, use nut fix it.




## 2) Assemble the head and handlebar


- 1.Assemble the windshield according to the picture, insert to the card slot, use two 3\*8mm self-taping screw fixed.
- 2.Put the dashboard well in the right place, assemble the head and handlebar with four 4\*16mm self-taping screw.



## 3) Assemble the handlebar and vehicle body

- 1.Takeout 8\*150mmscrew,match the head and body to the same hole, insert the screw into it,and use the nut fix it, according to picture B .
- 2.Connect the wires of light and body.





#### **4) Assemble the tool box and reflector**

1. Connect the two parts of the toolbox well, insert the tool box in the hole on the body.
2. Assemble the reflector, each side use two 3\*8mm self-taping screw fixed



#### **5) Connect the battery and assemble the seat**

1. Open the seat, connect the red wire to the red connector, black wire to the black connector. (If not connect well, vehicle can't work)
2. Assemble the seat into the right place use one screw fix it. and charge the vehicle first before use.

## OPERATING INSTRUCTION

---



1) Push the forward/stop/back switch on forward, Step on the pedal, vehicle will go forward , release the pedal, vehicle will stop; push the forward/stop/back switch on middle, vehicle will stop, push the forward/stop/back switch on back, step on the pedal, vehicle will go backward.

2) There is alarm and music button on the body, if you want to play it, press the button.

## USING NOTICE

---

1. Before use please check every component is well connected.
2. Can't use on street, road, slope, flume and any dangerous place
3. Can't use on smooth surface, such as marble floor tile and so on.
4. Can't change the circuit and any electric accessories.
5. Can't use the vehicle in the water ,can't put any water on the vehicle and be away from fire to avoid the damage of circuit.
6. When meet obstacle vehicle stop work, please leave obstacle and then play.
7. If not use, please turn off the power switch, if long time no use.the battery should be full ,unplug the battery plug.

## CHARGING INSTRUCTION

---

- 1) Charging must be operated by the adult, don't let children touch. When first use, the battery should be charged for 12 hours. Otherwise battery will be damaged.
- 2) When charging, first match the charger plug with the charging socket, then connect the electricity. When it is charging, the vehicle is not work .WARNING: The vehicle power switch must be closed when charging.
- 3) When the speed become slowly, you should charge for 8-12 hours, no more than 20 hours. If you don't charge promptly, the battery will be used up and will be permanently damage. When you finish charging, you should unplug the charger. otherwise the vehicle can't work.
- 4) When it is charging , both the charger and battery will have warm feeling.
- 5) If there is water in the plug can't charge.
- 6) Charging must use the battery and charger which is provided with this vehicle, don't use others.
- 7) When it is long time no use, should charge at least one time every month.

## EASY WAY TO SOLVE THE MALFUNCTION

Vehicle Can't Drive	1. Whether the battery plug is loose 2. whether the forward /stop/back switch on the stop gear 3. whether the fuse is broken, if broken. change a new one. which is under the seat in the transparent box
Vehicle Goes Slowly	1. whether it is overload 2. whether it is fully charged 3. whether the wheel got stuck by something
Can't Charge The Battery Full	1. whether the battery and charger is broken 2. the charger is well connected or not

NOTE: The product picture, function and introduction in this instruction is only for reference, which is subject to the real product.